

Host Initiated Transactions

Version 2.3

Document Revision Information

Version	Comments
0.1	Initial version.
0.2	Added Payline information.
0.3	Update to Document Formatting.
1.0	Release Version.
1.1	Signature support and Cancel transaction functionality.
1.2	Update to production endpoint address & transaction flow.
1.3	Removed DCC & Locate functions for now.
1.4	Added additional ReCo information & added Sandbox.
1.5	Added Paymark section updated images & fixed typos. Updated Void and Refunds. Included new configuration information.
1.6	Formatting changes.
1.7	Included cash out functionality.
1.8	Update to refund section and buttons.
1.9	Included multi-user testing.
2.0	Included additional ReCos and updated transaction completion response information.
2.1	Included Receipt transaction request.
2.2	Included Fail-Proof Result Notification functionality.
2.3	Rebranded Whole Document. Updated IWL250 documentation to Move5000 documentation - Lorenzo Fernandez



Copyright

© Copyright 2019, Windcave Ltd 33 Wilkinson Road, PO Box 8400 Auckland 1060 New Zealand www.windcave.com

All rights are reserved. No part of this work may be reproduced or copied in any form or by any means, electronic or mechanical, including photocopying, without the express written permission of Windcave Limited.

Proprietary Notice

The information described in this document is proprietary and confidential to Windcave. Any unauthorised use of this material is expressly prohibited except as authorised by Windcave Limited in writing.



Contents

1	Introduction	5
2	Operation	6
2.1	Endpoints & Firewall Considerations	6
3	Configurations	7
3.1	Direct external connection	7
3.1.1	Direct external connection iPP350	7
3.1.2	Direct external connection Move5000	7
3.2	Connection to PC	8
3.2.1	Connection to PC iPP350	8
3.2.2	Connection to PC Move5000	8
3.3	IPP350 with MTM200	9
3.4	3G connection with Move5000	9
3.5	Paymark key set up (NZ Only)	10
3.6	Terminal configuration	10
3.6.1	Initialisation	10
3.6.2	Logon	10
4	Transaction Flow	11
5	Message Specification	12
5.1	Transaction	12
5.2	Status	14
5.3	Buttons	17
5.4	Refunds	18
5.5	Receipt	19
6	Fail-Proof Result Notification (FPRN)	20
6.1	Fail-Proof Result Notification Transaction Flow	21
7	Response Codes	22
8	TxnStatusId & StatusId	23
9	Parameters	24
10	Real-time Transaction Monitoring	
11	Contact Windcave	




1 Introduction

The **Windcave Host Initiated Transaction (HIT)** solution is a web facing HTTPS service that permits control of a payment transaction on a Windcave terminal.

There is no requirement of a direct physical connection between the Point of Sale (POS) application and the Windcave terminal. All required software is on the Windcave Terminal and Host. All messages are sent online via the internet to create an end-to-end cloud-based payment solution.

The terminal can be connected online to a modem or router directly. However if required the HIT enabled terminal can be connected to a POS's PC as well to share the internet connection from the PC, in that case the POS's PC needs to have an SCR Controller software installed. For further details please refer to section 3 - Configurations.

The Windcave HIT sandbox is accessible online https://demo.windcave.com/SandboxPxHIT.aspx





2 Operation

The POS initiates a transaction request to Windcave by sending an HTTPS POST request as an XML message to the appropriate URL. See below section 2.1 (Endpoints & Firewall Considerations) for a list of URLs.

Windcave responds to the request, either immediately or after a configurable timeout period of a few seconds; after receiving a response, the POS will continue to make Status requests until the Status response indicates that the transaction is Complete (Complete value is returned as "1") in Result.

Status responses from Windcave may contain instructions for the POS to permit information to be displayed for the merchant (DL1, DL2) and enablement of buttons that may be used by the POS to interrupt the transaction or provide feedback for example signature capture.

Note: For any new integrations, the POS must handle the entry of new users. POS applications are typically used by many different customers.

As each customer has one or more HIT API users, a key part of POS development is ensuring that new user HIT API credentials can be easily added into the POS and that the development credentials are not hard coded in any way. Please ensure the API credentials configuration within the POS are also password protected or has some level of authorised access challenge.

2.1 Endpoints & Firewall Considerations

The POS can communicate with the Payment Host using **HTTPS** on the addresses below. Please ensure that your network can accommodate this access.

Production: https://sec.windcave.com/pxmi3/pos.aspx

Test: https://uat.windcave.com/pxmi3/pos.aspx

The Windcave HIT terminal communicates with the Windcave Host using **TCP** on the addresses below. Please ensure that your network can accommodate this access.

Production: scr.windcave.com port 65

Test: uat.windcave.com port 65



3 Configurations

3.1 Direct External Connection

Windcave HIT terminals can be configured to connect directly to an external Internet connection; this allows merchants to remove all physical connection between their POS and the payment device; this option is available for both the iPP350 and the Move5000.

No Windcave software is required on the PC running the POS. However only the Windcave key scheme is supported.

3.1.1 Direct External Connection iPP350

The iPP350 terminal is connected to an external network using three separate cables:





The customer must have a receipt printer and all receipt printing is controlled directly by the POS.

3.1.2 Direct External Connection Move 5000

The Move5000 terminal is connected for online connectivity to an external network (via a router or modem) using a







3.2 CONNECTION TO PC

Both the iPP350 and the iWL250 can be connected directly to the merchant's POS. In order to run the HIT device, the merchant must download the SCRController software from the Windcavewebsite.

Windcave and Paymark (NZ only) terminal key schemes are available.

3.2.1 Connection to PC iPP350

The iPP350 is connected directly to the POS using one USB-A cable:





The customer must have a receipt printer. The HIT response will contain the receipt content which is required to be printed by the POS's own receipt printer.

3.2.2 Connection to PC Move5000

The iWL25C terminal is connected directly to the POS using one USB-A cable. The device must also have power to the base.





All printing is handled directly by the terminal's on-board thermal printer.



3.3 IPP350 with MTM300

The iPP350 can be connected directly to the MTM300. The MTM300 includes a thermal printer and allows both Paymark and Windcave key schemes to be used. The MTM300/iPP350 connection requires two separate cables:



All printing is handled by the MTM300's on-board thermal printer.

3.4 3G Connection with Move5000

The Move5000 accepts SIM cards which allows it to communicate using 3G. No cable connection is required other than the standard power cable to the base.

Only Windcave keys can be used with this set up.



All printing is handled by the on-board thermal printer



3.5 Paymark key set up (NZ Only)


Terminals using the Paymark key scheme must have their keys remotely injected before transacting. Please contact our support team for assistance.

3.6 Terminal configuration

The Windcave terminal should come with preconfigured network settings. If there are any connectivity issues that cannot be resolved, please contact Windcave Support staff.


3.6.1 Initialisation


Once powered up, the device will go through an automatic boot-up and online logon process. Once completed & ready, PINpad will idle and display "EFTPOS" on the screen.





3.6.2 **Logon**

In order to prepare the terminal for processing transactions, the Logon message is used. A Logon uses the assigned merchant number and terminal ID to login to the banking switch. This is recommended but optional as the terminal will automatically log itself with the Windcave Host 10 seconds after connecting to the network. However if logon is required please do the following manual logon process. Press the "Menu" button on the PINpad, and select "LOGON".









5 Message Specification

This section describes communication aspects of the HIT XML messages specification.

5.1 Transaction

To initiate a transaction the following SCR XML message specified needs to be posted to the HIT POS endpoint.

5.1.1 Transaction Request – Input Parameters

Transaction request fields or properties to initiate a card present transaction with HIT

Property\[Attribute]	Required	Description
[user]	Yes	HIT Username provided by Windcave Alphanumeric, from 1 to 32 characters in length. Please ensure this is securely configurable via the POS config.
[key]	Yes	HIT Key provided by Windcave. Alphanumeric, from 1 to 64 characters in length. Please ensure this is securely configurable via the POS config.
Station	Yes	Station Id unique to the terminal. Alphanumeric, from 1 to 32 characters. Please ensure this is securely configurable via the POS config.
Amount	Yes	Amount of transaction in D.CC format. Where D is dollar and C is cent value. Numeric and decimal point, from 1 to 13 digits.
AmountCash	No	Amount for cash out. Numeric and decimal point, from 1 to 13 digits.
Cur	Yes	Currency of the transaction. Alphanumeric, 3 characters only allowed.
		Transaction Type. Valid values: Purchase, Auth, Refund or Status.
TxnType	Yes	Please note for requesting the Complete transaction after an Auth transaction from the terminal please use our PxPost or WebService API.
TxnRef	Yes	Set by POS to uniquely identify transactions. Alphanumeric, from 1 to 40 characters.
DeviceId	Yes	HIT POS identifier provided by POS. For example, a POS Lane Identifier etc. Alphanumeric, from 1 to 32 characters.
PosName	Yes	PosName – agreed between POS Vendor and Windcave. Alphanumeric, from 1 to 32 characters.
PosVersion	No	Version of POS. Supplied by POS to assist transaction recording and diagnosis. Alphanumeric, from 1 to 32 characters.
Vendorld	Yes	The developer of the POS Application. This is agreed between Windcave and vendor. Alphanumeric from 1 to 32 characters in length.
MRef	No	Merchant text field. Alphanumeric, max 64 characters. Recommend to use, useful for reporting purposes.
UrlSuccess	No	Set the URL to receive a HTTP GET notification on approved card present payment
UrlFail	No	Set the URL to receive a HTTP GET notification on declined card present payment

Example Transaction Request:

- <Scr action="doScrHIT" user="xxx" key="yyy">
- <Amount>1.05</Amount>
- <Cur>NZD</Cur>
- <TxnType>Purchase</TxnType>
- <Station>1234567890</Station>
- <TxnRef>123</TxnRef>
- <DeviceId>Device 1</DeviceId>
- <PosName>POS 1</PosName>
- <PosVersion>Pos V1</PosVersion>
- <VendorId>PXVendor</VendorId>
- <MRef>My Reference</MRef>
- </Scr>



5.1.2 Initial Transaction Status Response – Output Parameters

Property\[Attribute]	Description
TxnType	Transaction Type. Normally the HIT transaction response's TxnType value is
	as Status.
StatusId	Status of the current request.
TxnStatusId	Status ID related to current transaction.
Complete	If transaction is completed this field will be set to 1.
ReCo	Response Code indicating outcome. See 3 IntroductionResponse for a details description of ReCo values.
Tmo	Http Timeout in operation for the request.
TxnRef	TxnRef value for the original request and transaction.
DL1	Display Line 1. If not empty, the merchant display should display this on the uppermost lines.
DL2	Display Line 2. If not empty, the merchant display should display this on the lowermost line.
B1	Button1. If not blank, contains label for a button that permits the POS to interact with the transaction. The "en" attribute will be "1" if the button should be active and displayed.
B2	Button2. If not blank, contains label for a button that permits the POS to interact with the transaction. The "en" attribute will be "1" if the button should be active and displayed.

Example Status Response:

<Scr>

<TxnType>Status</TxnType>

<StatusId>3</StatusId>

<TxnStatusId>2</TxnStatusId>

<Complete>0</Complete>

<ReCo/>

<Tmo>20</Tmo>

<TxnRef>123</TxnRef>

<DL1>PRESENT/INSERT</DL1>

<DL2> SWIPE CARD</DL2>

<B1 en="0"/>

<B2 en="1">CANCEL</B2>

</Scr>



5.2 Status

5.2.1 Status Request

Request a Status for an active or historical transaction. Merchant POS should request this message shortly after the transaction is initiated as per section 5.1 (Transaction). The TxnRef must match the transaction the POS wants to do status check on.

```
Example Status:

<Scr action="doScrHIT" user="xxx" key="yyy">

<Station>1234567890</Station>

<TxnType>Status</TxnType>

<TxnRef>123</TxnRef>

</Scr>
```

5.2.2 Status Response

5.2.2.1 During Processing

The POS interface should always show any DL1 and/or DL2 text from the Status response to match the terminal screen prompt text. Note in below example the DL1 display message is set to Processing.

```
Example Status Response:

<Scr>
<TxnType>Status</TxnType>
<StatusId>4</StatusId>
<TxnStatusId>5</TxnStatusId>
<Complete>0</Complete>
<ReCo/>
<Tmo>20</Tmo>
<TxnRef>123</TxnRef>
<DL1>PROCESSING</DL1>
<DL2/>
<B1 en="0"/>
<B2 en="0"/>
</Scr>
```

5.2.2.2 Signature Stage

A receipt message will be available to print as well as prompts and mandatory button options YES' and 'NO'.

The POS should display the button options to the POS operator and a print button to print the physical merchant copy of the receipt for the customer to sign on. The POS system is required to accept or decline a signature transactions with the Yes or No button—please follow the messages for button request in section 5.3 (Buttons).

```
Example Status Response (Signature prompted):
 <TxnType>Status</TxnType>
<TxnRef>123</TxnRef>
 <StatusId>4</StatusId>
 <TxnStatusId>7</TxnStatusId>
<Complete>0</Complete>
 <RcptW>30</RcptW>
                           --EFTPOS-
                                       ----*27 Mar 18 13:35
                                                           CREDITSWIPE VISA
 <Rcpt>
                                                                                CARD
476173*****0010AUTHORISATION
                                   025211REFERENCE
                                                            029017PURCHASE
                                                                               NZD1.08TOTAL
                                                               MERCHANT COPY PLEASE RETAIN FOR YOUR REC-
NZD1.08
          APPROVED PLEASE SIGN BELOW
ORDS</Rcpt>
 <ReCo></ReCo>
 <Tmo>20</Tmo>
 <TxnRef>123</TxnRef>
<DL1>SIGNATURE OK?</DL1>
<DL2>YES/NO</DL2>
<B1 en="1">YES</B1>
<B2 en="1">NO</B2>
</Scr>
```



Please Note: It is important that the POS integration continues to request a status check until after the POS user appropriately handles the prompt on the POS and/or terminal and the final response contains the Complete tag value as 1. The HIT interface allows only one transaction to be fully completed at a time. A pending transaction completion will result in an "Existing Txn In Progress" error. This should be handled by sending the Status request for the TxnRef of the transaction until it reaches the Complete stage.

5.2.2.3 Final Status Response on completion of Transaction

On completion of a transaction the Complete XML element will be set to 1. The result of the transaction will be populated inside the Result XML element. Below property elements are contained in the transaction response and Result XML element.

Property	Description
TxnType	Transaction Type. Normally the HIT transaction response's TxnType value is as Status.
TxnRef	TxnRef value for the original request and transaction.
StatusId	Status of the current request Refer to the section TxnStatusId and StatusId for more information.
TxnStatusId	Status ID related to current transaction.
Complete	If transaction is completed this field will be set to 1.
RcptW	Receipt Width specifies the maximum character limit per receipt content's line. A terminal's account is setup with a default receipt width character length. The fixed character limit can be used to center justify the receipt content per line to get the standard receipt format.
Rcpt	Actual EFTPOS receipt content that should be physically printed in case the POS handles the EFTPOS receipt printing. All receipt content should be printed to ensure financial data integrity.
Result	Encloses the final transaction results with specific transaction data fields.
AC	AuthCode. Up to 6 character authorisation code.
AP	Approved flag. "1" indicated approved (funds transfer or reserve); "0" indicated declined or not approved.
CN	Masked Card Number.
Complete	1 indicates transaction session is completed. The POS should stop sending status requests
СТ	Card Name e.g. Visa.
DS	Expected Settlement Date of Transaction. Format is yyyymmddhhmmss.
DS_TZ	TimeZone applied to the DS value.
DT	Date of Transaction. Returned in Timezone Format is yyyymmddhhmmss.
DT_TZ	TimeZone applied to DT value.
PIX	EMV specific data.
RID	EMV specific data .
RRN	Retrieval reference Number
ST	STAN. The System Trace Audit Number which identifies the transaction number processed through the merchant account.
TR	DpsTxnRef. Unique global transaction identifier generated by Windcave and returned for every transaction. This value can be provided to support teams to identify transactions.
DBID	DpsBillingId is a card token generated by Windcave. Token used to rebill the card for subscription or recurring based payments. Rebilling requests are sent via the PxPost or Webservice API.
RC	Response Code. See section 6 Response Codes
RT	Response Text. See section 6 Response Codes.
RTT	Round Trip Time in Milliseconds –provides an indication of network health (between Windcave and Windcave Terminal).
AmtA	Amount value of the transaction in cents.



```
Example Final Status Response (Completed):
<TxnType>Status</TxnType>
<TxnRef>123</TxnRef>
<StatusId>6</StatusId>
<TxnStatusId>8</TxnStatusId>
<Complete>1</Complete>
<RcptW>30</RcptW>
                          ---EFTPOS-----*27 Mar 18 13:13
                                                          CHEQUESWIPE VISA
                                                                                     CARD
<Rcpt>
411111*****1111AUTHORISATION
                                                           029013PURCHASE
                                  000289REFERENCE
                                                                                  NZD1.00TOTAL
                          APPROVED
NZD1.00
                                                           PIN VERIFIED
             CUSTOMER COPY
                                                   PLEASE RETAIN
                                                                        FOR YOUR RECORDS</Rcpt>
 <Result>
 <AC>000289</AC>
  <AP>1</AP>
 <CN>411111*****1111</CN>
 <CT>Visa</CT>
 <CH>VISA TEST CARD/</CH>
  <DT>20180327131306</DT>
 <DT_TZ>NZT</DT_TZ>
 <DS>20180327180000</DS>
 <DS_TZ>NZT</DS_TZ>
 <PIX></PIX>
 <RID></RID>
 <RRN></RRN>
  <ST>788359</ST>
 <TR>0000000100e1a6f9</TR>
 <DBID>0000010001128730</DBID>
 <RC>00</RC>
 <RT></RT>
 <RTT>4050</RTT>
 <AmtA>100</AmtA>
 </Result>
 <ReCo></ReCo>
 <Tmo>20</Tmo>
 <TxnRef></TxnRef>
 <DL1>APPROVED</DL1>
 <DL2></DL2>
 <B1 en="0"></B1>
<B2 en="0"></B2>
</Scr>
```



5.3 Buttons

POS is required to display appropriate buttons if B1 or B2 field in the XML response(s) is not blank. Once any button is clicked, the POS should then post appropriate button request to SCR endpoint.

Property	Description
Station	Station Name of the Windcave terminal being selected by the POS.
TxnType	For Button Request, the value should be UI for User Interface.
UiType	Bn
Name	B1 or B2. Depending on the button pressed.
Val	Value to be sent with the request for button press - CANCEL, YES, NO.
TxnRef	Transaction reference assigned by POS. This should be different for each transaction.

5.3.1 Button Request XML

Example Button: <Scr action="doScrHIT" user="xxx" key="yyy"> <Station>1234567890</Station> <TxnType>UI</TxnType> <UiType>Bn</UiType> <Name>B1</Name> <Val>YES</Val> <TxnRef>12345678</TxnRef> </Scr>

5.3.2 Button Response XML Example

```
Example Button Response:

<Scr>
<TxnType>UI</TxnType>

<TxnRef>12345678</TxnRef>

<Success>1</Success>

<RC></RC>

</Scr>
```



5.4 Refunds

5.4.1 Matched refunds initiated via HIT request

To initiate a refund directly from the POS, the DpsTxnRef of the initial transaction must be included. The unique TxnRef is used separately as a reference to the refund and must be unique.

Example Matched Refund:

- <Scr action="doScrHIT" user="xxx" key="yyy">
- <Amount>76.00</Amount>
- <Cur>NZD</Cur>
- <TxnType>Refund</TxnType>
- <Station>1234567890</Station>
- <TxnRef>987</TxnRef>

<DpsTxnRef>0000005400911209/DpsTxnRef>

- <DeviceId>1234567890</DeviceId>
- <PosName>POS 1</PosName>
- <PosVersion>Pos V1</PosVersion>
- <VendorId>DPSVendor</VendorId>
- <MRef>My Reference</MRef>
- </Scr>

5.4.2 Unmatched refunds with refund card

To initiate a refund directly from the POS and authorise with a merchant refund card, the following example XML should be modified and sent. The DpsTxnRef tag does not need to be included, instead for authorization the terminal will prompt for the merchant's refund card to be swiped and PIN entered before the customer presents their card for the refund. The merchant refund card is setup by Windcave. For extra security, it is expected the POS requires own authorization before requesting unmatched refund via the POS.

Example Unmatched Refund:

- <Scr action="doScrHIT" user="xxx" key="yyy">
- <Amount>76.00</Amount>
- <Cur>NZD</Cur>
- <TxnType>Refund</TxnType>
- <Station>1234567890</Station>
- <TxnRef>987</TxnRef>
- <DeviceId>1234567890</DeviceId>
- <PosName>POS 1</PosName>
- <PosVersion>Pos V1</PosVersion>
- <VendorId>DPSVendor</VendorId>
- <MRef>My Reference</MRef>
- </Scr>

5.4.3 Matched refunds via ecommerce solution

The PxPost or Web Service eCommerce API can be used to process refunds with the matched DpsTxnRef of the given HIT transaction. For more information on PxPost and Web Service, please visit our website

https://www.windcave.com/developer-e-commerce-merchant-hosted-transaction-processing

When using PxPost or Web Service to handle refunds, the HIT user and the eCommerce API user must be associated with the same Windcave Group; for additional information please contact our Support team.



5.5 Receipt

In case the POS requires to request the last EFTPOS receipt content to print, the POS can send a request to receive the last transaction's receipt content with the most recent or last transaction's TxnRef. This can be requested to reprint the receipt when a printer and it's paper roll is available. Following are the request and response details specific to get the last receipt.

5.5.1 Receipt Request XML

Property	Required	Description
Station	Yes	Station Name of the Windcave terminal being selected by the POS.
TxnType	Yes	For Receipt Request, the value should be Receipt.
TxnRef	Yes	The most recently processed transaction's transaction reference.
DuplicateFlag	No	An optional tag. If value 1: Includes a DUPLICATE RECEIPT text string on the receipt content. Otherwise 0 will not include the duplicate text string.
ReceiptType	Yes	A flag indicating the receipt content type to receive. Valid Values:
		1 = Merchant Copy of receipt with a signature placeholder (only for signature transaction)
		2 = Customer Copy of receipt
		3 = Merchant Copy of receipt

Example Receipt Request:

<Scr action="doScrHIT" user="xxx" key="yyy">

- <Station>4012345678</Station>
- <TxnType>Receipt</TxnType>
- <TxnRef>12345</TxnRef>
- <DuplicateFlag>0</DuplicateFlag>
- <ReceiptType>2</ReceiptType>
- </Scr>

Property	Description
RcptW	Receipt Width specifies the maximum character limit per receipt content's line. A terminal's account is setup with a default receipt width character length. The fixed character limit can be used to center justify the receipt content per line to get the standard receipt format.
Rcpt	Actual EFTPOS receipt content that should be physically printed in case the POS handles the EFTPOS receipt printing. All receipt content should be printed to ensure financial data integrity.

PLEASE RETAIN

5.5.2 Receipt Response XML

Example Receipt Response:

<Scr>

<TxnRef>12345</TxnRef>

<TxnType>Receipt</TxnType>
<RcptW>30</RcptW>

<Rcpt> -EFTPOS-----*18 Apr 18 11:06 499999******9103AUTHORISATION 011498REFERENCE **APPROVED** AUD1.00

CUSTOMER COPY

</Scr>

CHEQUESWIPE VISA 009451PURCHASE PIN VERIFIED

FOR YOUR RECORDS</Rcpt>

CARD AUD1.00TOTAL



6 Fail-Proof Result Notification (FPRN)

Fail-proof result notification (FPRN) is a service that provides additional assurance that the merchant website will receive notification regarding the outcome of transactions completed via the Windcave host. This service allows merchant POS to stop checking for the status stage after the transaction is initiated and simply indicate finalization of the transaction.

FPRN can be enabled by adding <UrlSuccess> and <UrlFail> parameters in the request. Notification will be sent by Windcave host once the transaction is finalised. Windcave host will only send FPRN notification when the response result of TxnStatusId is 7 – Verifying Signature and 8 – Display Result. However, it is recommended displaying a user -friendly prompt such as "Transaction in progress—Please refer to terminal" on the screen of POS. The only case that the POS would still have to display prompts/buttons is when the terminal must require user selection (TxnStatusId = 7) for approving signature with mandatory button options 'YES' and 'NO'.

As soon as the response result of TxnStatusId is 7 or 8, a background process at Windcave makes an HTTP GET request to the merchant-nominated success or failure URL. If the merchant web site is unreachable or returns any HTTP status code other than 200, 201, 302, 303, 404 or 502 the HTTP GET is retried up to a maximum of six times. It will give up immediately on receiving a 404 (page not found) HTTP status code or 502 (Bad Gateway) HTTP status code. A 500 HTTP status code, indicating a temporary problem at the client site, will cause a retry.

Please note that merchant POS would still have to perform the status request after the transaction is initiated if they want to update prompts for every stage on the screen of POS.

To ensure that the web application is in the best position to acknowledge the outcome of every transaction, certain guidelines should be followed.

The merchant web application should not;


- Filter or base any conditional logic upon the originating IP address (this can vary)
- Depend upon receiving one and only one request for the success/fail URL from the Windcave FPRN system (multiple requests may be sent).

N.B. The URL at which the merchant website will process FPRN requests must be exposed via standard internet ports i.e. port 80 or port 443 for SSL/TLS traffic. When specifying UrlSuccess and UrlFail values do not specify a non-standard port number within the URL.

Example Transaction Request with FPRN:

- <Scr action="doScrHIT" user="xxx" key="yyy">
- <Amount>1.05</Amount>
- <Cur>NZD</Cur>
- <TxnType>Purchase</TxnType>
- <Station>1234567890</Station>
- <TxnRef>123</TxnRef>
- <DeviceId>Device 1
- <PosName>POS 1</PosName>
- <PosVersion>Pos V1</PosVersion>
- <Vendorld>PXVendor</Vendorld>
- <MRef>My Reference</MRef>
- <l
- \$\$ <UrlFail>https://webhook.site/d85dd2b9-c1c0-4a5f-8109-bcf8b22eaab6?txnRef=12345&station=1234567890</UrlFail></Scr>





7 Response Codes

ReCo	Description
P4	PosDeviceId is greater than 32 characters
P5	PosDeviceId not matched
P7	Invalid transaction type
P8	Authentication error
P9	Authentication error—Station Id mismatch
PA	Status request error
PB/PC	SCRHIT Init Session Error
PC	Existing Txn In progress—previous transaction was left in an incomplete state, ensure sending status request of the previous transaction and it's reference and status response is handled accordingly.
PD/PE/PF	SCRHIT Transmit Error— network connection issue, ensure the terminal has performed a Logon to the Windcave HOST.
PG	Init Wait Timeout
PJ	TxnRef not matched
PK	SCRHIT not enabled
PL	Invalid input parameter
PM	Txn type not allowed
PO	Invalid Station Id
TQ	HIT Start Failed— connection lost, ensure the terminal has performed a Logon to the Windcave HOST.



8 TxnStatusId and StatusId

The TxnStatusId is the Status ID related to the current transaction and terminal prompt. StatusId is the status of the current request.

TxnStatusId

Id	Description
1	Idle
2	Present Or Insert Card
3	Select Account
4	Select App
5	Enter Pin
6	Processing
7	Verifying Signature
8	Display Result

StatusId

ld	Description
1	Initiating
2	Transaction Started
3	Transaction Started
4	Processing
5	Authenticating
6	Transaction Completed

9 Parameters

The **HIT request parameters** are supplied as either XML elements or attributes. Some parameters are mandatory (must be included and non-blank), while others are optional.

Amount

Amount of the transaction type. Decimal point is mandatory.

AmountCash

Amount of cash out required. Decimal point is mandatory.

EnableAddBillCard flag (optional) and BillingId (optional)

Set the EnableAddBillCard flag to 1 and POS supplies a unique BillingId that can be associated with card data for tokenizing a card and use for future automated rebilling or recurring payment via an eCommerce API (PxPost or WebService). BillingId has to be 1-32 characters in length. Otherwise the DpsBillingId (DBID) in the final transaction response can be used as a card token that is automatically generated by Windcave.

Cur

Specifies the standard three letter Currency Code for the transaction. The standard currencies supported depends on the merchant's account configuration in the Windcave system.

DeviceId

POS identifier provided by POS. For example, a POS Lane Identifier etc. Alphanumeric, from 1 to 32 characters.

EnableTip (optional)

If set to 1, enables prompting for a Tip (gratuity) in hospitality situations. Valid for Auth or Purchase transactions.

HttpTimeout (optional)

Timeout in seconds to be applied by Windcave to HIT Client HTTP POST requests. If supplied, value must be between 10 and 60.

MRef (optional)

Merchant reference applied to the transaction. Mostly used for transaction reporting purposes. Up to 64 characters alphanumeric.

PosName

PosName - agreed between POS Vendor and Windcave.

PosVersion

Version of POS. Supplied by POS to assist transaction recording and diagnosis. Alphanumeric characters between 1-32 characters.



Station

Station is the serial number value as a Station Name of the Windcave terminal being selected by the POS.

TxnRef

Transaction reference assigned by POS. This should be unique for each Purchase, Auth or Refund transaction.

TxnType

Value	Description
Purchase	Purchase Transaction
Auth	Auth a card for certain amount
Status	To receive the current status of the HIT terminal and HOST process
Refund	To Refund a Purchase or Complete Transaction

For more information please refer to <u>Transaction Type Information</u>.

TZ (optional)

Time zone to be applied to returned time values including times printed on receipt. If not supplied, the time zone configured by Windcave for the terminal is applied.

Value	Description
AEST	Australia Eastern Time (Sydney)
AESTQL	Australia Eastern Time (Queensland)
NZT	New Zealand Time
UK GMT	UK Time
US CST	United States Central Time
US EST	United States Eastern Time
US MST	United States Mountain time
US PST	United States Pacific Time

Val

Value to be sent with the request for the button press - CANCEL, YES or NO.

Vendorld

The developer of the POS Application. This is agreed between Windcave and vendor. Alphanumeric from 1 to 32 characters in length.



Any transactions processed via the Windcave® HIT terminal can be monitored in real-time from any device with access to internet and a web browser.


You can logon to the **Payline**® web portal at the address below using the **username** and **password** provided with your account.

Live transactions portal: https://sec.windcave.com/pxmi3/logon

Test transactions portal: https://uat.windcave.com/pxmi3/logon

In addition to monitoring transactions in real-time, the Payline® web portal can configured to download transaction reports, view invoices, view payments and also process manual transactions online.

For more information on Payline®, phone Windcave® Sales on 0800 PAYMENT (729 6368) or email sales@windcave.com.





General Support Queries - support@windcave.com Technical/Integration Queries - devsupport@windcave.com Sales Queries - sales@windcave.com

New Zealand

Auckland

Phone (landline)

0800 PAYMENT (729 6368)

Phone (mobile)

+64 9 309 4693

Fax

+64 9 309 4694

Address

33 Wilkinson Road, Ellerslie Auckland

New Zealand

Australia

Sydney

Phone

1 800 006 254 or +61 2 8268 7700

Fax

1 800 469 709

Address

Level 3, 503-505 Kent Street Sydney, NSW 2000

Australia

United Kingdom

London

Phone

0800 088 6040 or +44 (0) 2 037 523 340

Fax

+ 44 (0) 808 280 2432

Address

164 - 180 Union Street

LI. 313

Southwark, London

SE1 0LH

USA

Los Angeles

Phone

1 877 434 0003 or

+1 213 378 1190 or

+1 310 670 7299

Fax

+1 310 670 7298

Address

8939 South Sepulveda Boulevard,

Suite 520

Los Angeles, CA 90045

USA

Rest of the World

Canada Republic of Ireland

Phone Phone

+1 844 221 2700 or 1800 930 220

+1 778 807 5107

Singapore International Phone Phone

+65 315 81353 +64 9 309 4693

Address

Hong Kong Windcave

Phone (landline) P O Box 8400 +85 258 033032 Auckland 1150

New Zealand